



# Accu-Feed LTD

## LOW TENSION DEREELER

The Accu-Feed LTD Low Tension Dereeler is designed to provide **constant strain, low tension payout** of tubing to an Accu-Cut or other machine for **high volume, critical tolerance manufacturing** operations. It features a **low mass, nonstatic proportional speed dancer arm**. The LTD is torque-limited for safety and does not require any electrical connection to its host machine.



### KEY FEATURES

- Designed for high-volume, critical tolerance manufacturing
- Precision ball-bearing construction for low dancer arm friction
- Torque-limited for safety
- Communicates with Accu-Cut machines
- Incorporates static-reducing technology for cleanliness

### SPECIFICATIONS

**Speed:** 120rpm

**Maximum OD:** 0.25" (6.4mm)

**Maximum spool diameter:** 17.75" (0.45m)

**Maximum spool width:** 10" (0.25m)

**Maximum spool weight:** 12 lbs. (5.4kg)

**Power:** 100-240VAC at 50/60Hz

**Dimensions:** 30" x 15" x 20" (75" x 40" x 50" cm)

**Weight:** 20 lb. (9kg)