

Cathtip 400 Series

Semi-Automated Hole Drilling Machine

The 400 Series is a precision hole drilling machine that delivers results to the highest industry hole quality standards and is custom built to suit your application's specifications, including:

- Hole sizes down to 0.015"
- Multi-lumen configurations ranging from 2-8+ lumens
- (able to precisely locate & perforate individual lumen)
 - Materials from soft silicones to harder polymers



The CATHTIP proprietary Flow Thru[™] Hollow Drill's refined process control, and manufacturing excellence have made its machines a staple of most major catheter production clean rooms.

KEY FEATURES

- Flow Thru[™] core evacuation
- Razor sharp cutting edges drill edge diameter sharpened to +/- 0.0007"
- Burr-free holes
- Long drill life hardened SS440C
- · Tool less drill change
- Custom design setup & processes
- On-site support and training
- Safety light curtain

SOLUTION FLEXIBILITY

- Multi-lumen configurations from 2-8+ lumens
- Holes sizes down to 0.015
- Up-to 4 holes per second
- 1.5" OD
- Collet-style drill head for punches & ejector pin (optional)

SPECIFICATIONS

- Motion: Stepper
- Power: 100-240 AC at 50/60Hz
- Air: 100psi max. 5cfm
- Interface: Touchscreen
- Dimensions: 31" x 18"x 12"
- · Weight: 60lbs



CATHTIP is proud to be an MMT company – the sole source for automated, process-driven medical manufacturing. Medical Manufacturing Technologies (MMT) brings together applications expertise, technical solutions, and aftermarket support to revolutionize medical device manufacturing. Learn more at mmt-inc.com.

FOR PRODUCT INFO VISIT cathtip.com Revised 07.16.24