



ProCenter Plus

All-In-One MicroBlasting Work Station

Designed specifically for MicroBlasting, ProCenter Plus combines a compact dust collector and chair-height work chamber in one freestanding unit, creating a clean, comfortable work environment with great visibility.

The perfect companion to AccuFlo, ProCenter Plus combines all necessary accessories into one self-contained system on wheels. The unit rolls easily through any standard doorway and has a footprint of only 30" x 34" so you can blast wherever the work is.

Even Quieter

Our engineers designed the latest ProCenter Plus to reduce noise without sacrificing efficiency. This compact system not only does a better job of collecting spent abrasive, it does so more quietly, operating at a sound level of just 68 dBA.

Even Cleaner

ProCenter Plus comes equipped with an easy-to-replace HEPA filter. Spent abrasive is swiftly evacuated from the chamber, keeping the work area clean. HEPA air filtration means 99.97% of all particles greater than 0.3 micron in size are removed.

Easy to Maintain

Spent abrasive is quickly evacuated from the blast chamber and captured in the media hopper. Disposal is simplified with 2 large butterfly valves.



Key Features

- Downdraft design and HEPA filter equipped
- Blow off gun to clean parts quickly with a blast of air
- Extra large storage hopper for spent abrasives
- Built in Silencer
- Minimized air discharge
- Acoustically designed fan box for maximum noise reduction
- Ergonomic design with wide cushioned hand openings
- Large, well lit operator viewing area
- Large hinged window for easy parts handling
- Compatible with any Comco blaster

To learn more about the ProCenter Plus, including a comprehensive list of features and specifications, please visit:



ProCenter Plus

All-In-One MicroBlasting Work Station

Machine Specifications

Models:	CTR202-1 and CTR202-2 Standard Unit	CTR202-E-1 and CTR202-E-2 ESD Control Unit
Available in:	115V / 60Hz / 290W or 230V / 50Hz / 290W	115V / 60Hz / 290W or 230V / 50Hz / 290W
Size:	30" wide x 46" high x 34" deep	30" wide x 46" high x 34" deep
Interior Space:	2.2 cubic feet 24" wide x 14" deep x 10" (approx.)	2.2 cubic feet 24" wide x 14" deep x 10" (approx.)
Window:	Tempered glass opening (hinged) 23" x 11"	Tempered glass opening (hinged) 23" x 11"
Weight:	162 lbs / 73.5 kg	162 lbs / 73.5 kg
Lighting:	LED light strip	White and black LED light strip
Air Flow:	500 SCFM	500 SCFM
Filter:	HEPA- 99.97% efficiency on 0.3 micron-sized particles	HEPA- 99.97% efficiency on 0.3 micron-sized particles
Filter area:	30 ft ²	30 ft ²
Inlet Air Pressure:	80 psi air supply of 4 SCFM required in addition to normal blaster supply	80 psi air supply of 10 SCFM required in addition to normal blaster supply
Sound level:	68 dBA	68 dBA
Compatibility:	Works with all models of Comco micro-abrasive blasters	Works with all models of Comco micro-abrasive blasters



Comco is proud to be an MMT company – the sole source for automated, process-driven medical manufacturing. Medical Manufacturing Technologies (MMT) brings together applications expertise, technical solutions, and aftermarket support to revolutionize medical device manufacturing.